

HOFFMANN POWER PRODUCTS

PARTS LIST 2014

HOFFMANN GENERATOR

H6000E




[ALL PARTS ARE SUBJECT TO STANDARD HOFFMANN TERMS AND CONDITIONS OF SALE 2010](#)

Replacement parts are not manufactured, sold or warranted by O.E.M's and any part numbers and or descriptions are used for identification purposes only.


Manufacturers names, numbers and descriptions are used for reference purposes only and it is not implied that any part listed is the product of the manufacturers.

All pictures and drawings are for reference purposes only; any specifications appearing in any documents emanating from The Company are approximate only and are subject to modifications without notice.


All rights reserved, material contained in this publication for which copyright is acknowledged. No part of this publication may be reproduced or transmitted in any form or by any means without written permission of the copyright holder. Copyright Hoffmann International©2012.




No	Description	QTY.	Part No.
1	Bolt, Cycl Head Assy		
2	Cover Comp. Head		
3	Pkg. Head Cover 1.5 ^{mm}	20	
4	Breather Tube		6HG-102247-706
5	Nut, Pivot M6		
6	Nut, Pivot Adj M6 Hex Nut		
7	Arm, Valve Rocker	20	
8	Bolt Pivot M6XM8X531		
9	Retainer, In.Valve Spring		
10	Rotator, Exh Valve		
11	Retainer, Exh Valve Spring		
12	Valve Spring		
13	Retainer, In. Valve Spring		
14	Seal, In Valve		
15	Limit Position Panel		
16	Bolt Flange M10X80		
17	Spark Plug NGK BP6ES		
18	Bolt, Stud M8X48.5		
19	Gasket Muffler		6HG-213008
20	Spring Washer		




21	Hex Nut M8		
22	Comp. Muffler		6HG-213100
23	Flange Bolt M6X12		14Y-GB5787-86
24	Washer Φ8		
25	Flange Bolt M8X40		
26	Supporting Leg, Muffler		
27	Flange Nut M8		
28	Flange Bolt M6X12		14Y-GB5787-86
29	Wind Lead Cover		
30	Cycl Head	10	
31	Bolt, Stud M6XM8X110		
32	Gasket, In. Valve		6HG-109001
33	Insulator, Carb Comp		6HG-209002
34	Pkg. Carb		6HG-109003
35	Carburettor Assy		6HG-209100/6HGE-209100
36	Gasket Air Filter		6HG-112001
37	Air Filter		6HG-115000/HSE
38	Flange Nut M6		GBT6177-86/6
39	Supporting Leg A/C		
40	Gasket, Cyl Head		
41	Dowel, Pin		




42	Exh. Valve		
43	In. Valve		
44	Rod, Push		
45	Lifter Valve		
46	Ring Set, Piston		
47	Clip Piston Pin		
48	Piston		
49	Pin Poston		
50	Conrod Assy		
51	Drain Plug		13-02010003
52	Alum Washer		13-02010004
53	Crankcase		6HG-02010000
54	Shaft, Governor Arm		
55	Gasket, Governor Arm		
56	Seal, Governor Arm		
57	Pin		
58	Flange Bolt M6X10		9HG-6X10
59	Oil Sensor		
60	Clamp, Pin Lock		
61	Alert Unit, Oil		14Y-09030000
62	Flange Bolt M6X10		9HG-6X10




63	Cam Shaft Assy	10	
64	Bearing		
65	Governor Shaft	4	
66	Flange Bolt		
67	Governor Rod		
68	Adj Spring		
69	Governor Arm		
70	Bolt, Governor Arm		
71	Flange Nut		
72	Spring Throttle Return		
73	Control Assy (Throttle)		6HG-07100000
74	Crank Assy		6HG-104160
75	Gasket Crankcase		6HG-103002
76	Dowel, Pin		
77	Bearing 6207		
78	Bearing 6207		
79	Governor Assy	10	
80	Dipstick		6HG-204001
81	Stator and Rotor Stator and Rotor 3 Ph/6KVA		6HG-Stator & Rotor 6HGE/3P-ST/Rot }
82	Plate Washer		




83	Flange Bolt, Rotor M10X265		M10X265-6HG-80110-0310 6HG-M10X265	}
84	Flange Bolt M5X12			
85	End Covers		6HG-ALT/RCover	
86	Flange Bolt M5X16			
87	AVR 5kw		6HG/3P-228200/6HG-228200	
88	Generator Stay			
89	Flange Bolt M6X1160			
90	Flange Bolt M5X198			
91	Ball Nut M5			
92	Spring Gasket			
93	Anti-Duct Rubber			
94	Flange Bolt			
95	Cover, Crankcase		6HG-203001	
96	Oil Seal			
97	Wind Lead Cover			
98	Flange Bolt M5X12			
99	Rubber Plate			
100	IG Coil Assy		6HG-09040000/C	
101	Flange Bolt			



102	Flywheel Comp		6HGE-09050000
103	Cooling Fan		6HG-228155
104	Starting Cup		
105	Flange Nut M16		8-08000002
106	Recoil Starter Assy		6HG-08010000
107	Flange Bolt M6X10		9HG-6X10
108	Starting Motor Assy		6HG-116100/6HG-209100/6HGE-09060000
109	Flange Bolt M8X32		
110	Charging Coil AC20		6HGE-09070000
111	Flange Bolt M6X30		
112	Starter – Solenoid – 6HG-116200/6HGE-09080000		
113	Connecting Cord		
114	Cap. Relay		
115	Cord Fix Plate		
116	Frame Assy		6HG-1000620
117	Bottom Rubber		
118	Flange Nut M8		
119	Flange Nut M10		
120	Battery Supporting Leg		
121	Flange Bolt		



122	Battery Plate		
123	Battery Cover		
124	Equipment Plate		
125	Bolt M6X215		
126	Nut		
127	Frame Washer		
128	Flange Bolt		
129	Flange Nut		
130	Nega Cord. Battery		6HG-229151
131	Positive Cord. Battery		6HG-229152
132	Handle Assy		
133	Plastic Handle Set		
134	Rubber Handle Tube		
135	Washer		
136	Flange Bolt M8X60		
137	Flange Nut M8		
138	Kit Assy	10	6HG-E50400
139	Cotter Pin		
140	Grommet		
141	Clamp		
142	Supporting Assy		



143	Flange Bolt M8X16		
144	Flange Nut M8		
145	Rubber Mounting – L/H-6HG-227351		
146	Mounting Rubber R/H – 6HG-227352		
147	Flange Nut M6		
148	Control Panel Assy		6HGE-226000/6HG-226000
149	Flange Bolt M6X20		
150	Fuel Tank Assy		6HG-214100
151	Flange Bolt M6X25		
152	Tank Rubber		6HG-E40202
153	Fuel Filter		6HG-214001
154	Clamp		} 6HG-06000005
155	Fuel Tube		
156	Air Filter Element - Sponge		6HG-212158
157	Air Filter Base		6HG-115000
158	Air Filter Case c/w Clips		6HG-212154
159	Exhaust Pipe		6HG-213007